

Remotely controlling digital cameras with gPhoto

# IN CHARGE

Commercial software that lets users remotely control their camera usually is not available for Linux. gPhoto gives users a free alternative.

#### BY CHRISTIAN BAUN

ome vendors offer commercial add-ons to help users remotely control their cameras – for example, to take a series of photos at set intervals. Time exposures of the night sky and time-lapse photos of a growing plant are excellent choices of subject as well. However, vendors such

#### **Gtkam Graphical Front End**

The gtkam graphical front end (Figure 1) currently has only a rudimentary set of functions, although it does vastly simplify image downloads. From the dropdown menu, you can select the connected digital camera and use the thumbnails to navigate through your collection of images. Gtkam does not support remote control functionality for digital cameras. Applications such as the KDE digiKam [3] tool offer more convenience than gtkam.

as Canon and Nikon only offer their software for Windows and the Mac OS, and Nikon even charges for the program [1]. To make things worse, the software is closed source and not suitable for scripting, which tends to restrict its usefulness.

#### **gPhoto**

The gPhoto [2] project mainly comprises

the libgphoto2 library, the gphoto2 command-line interface, and the gtkam front end (see also the "Gtkam Graphical Front End" box). The software lets users read and change the status of their digital cameras, copy files in both directions, and

remotely control digital cameras.

As of this writing, gPhoto supports more than 1,100 digital camera models. A lack of cooperation on the part of camera manufacturers has forced developers to reverse engineer most of the protocol information and explains why the software does not support all of the features that are available on every single digital camera.

Although most state-of-the-art digital cameras that support simple tasks – such as transferring images – use the popular Picture Transfer Protocol (PTP) standard, the remote control protocols are typically undocumented. The examples in this article have been tested on a Canon 50D and should work with any digital camera supported by gPhoto with slight modifications (especially with Canon models).

#### **Data Management**

Before you start working with gPhoto, determine whether your camera's transfer mode is set to PTP; otherwise, the program will not support it. To find out whether gPhoto has correctly identified your camera, type *gphoto2* --auto-detect at the console to see the following output:

In this example, the software found a Canon 50D. The *gphoto2 --summary* command provides some basic information about the camera, including the memory card (capacity and space usage), designation, serial number, firmware version, and supported file formats. If you set the *-list-files* flag, you also get a listing of all the images on the memory card. To download the images, try *--get-all-files*.




Figure 1: The gPhoto gtkam graphical front end makes transferring images child's play, although it does not support remote control.

### Listing 1: Listing Configuration Parameters

### \$ gphoto2 --set-config capture=on --list-config

/main/settings/eos-time
/main/settings/eos-synctime
(...)
/main/imgsettings/eos-iso
/main/imgsettings/eos-whitebalance
/main/capturesettings/
eos-exposurecompensation
/main/capturesettings/picturestyle

Table 1 lists a selection of file and directory management options.

#### **Remote Control**

(...)

Although file downloads work with some 1,100 digital camera models, remote control through gPhoto works with less than 10 percent [4] of them. Most of the supported models are made by Nikon and Canon, and the function is not available at all for cameras by Samsung, Sigma, and Sony.

The *gphoto2 --list-config* command lists all supported functions offered by the software for the connected camera. For Canon SLR cameras such as the 50D and 400D, you can add *capture = on* to get a full list of configuration parameters (Listing 1). The *--get-config* switch reads all the configuration parameters and their possible values; *--set-config* assigns

### Listing 2: ISO Settings for the Canon EOS

Label: EOS ISO speed Type: RADIO Current: 400 Choice: 0 Auto Choice: 1 100 Choice: 2 200

(...) Choice: 6 3200

a parameter. For example, the command in Listing 2 tells gPhoto to output all available ISO settings.

To set the ISO value to 1600, simply type *gphoto2* --set-config capture = on --set-config eos-iso = 1600. The supported values for configuration parameters such as the ISO setting (eos-iso), exposure compensation (eos-exposurecompensation), white balance (eos-whitebalance), or picture style (picturestyle) depend on the camera you are using. The available values for the aperture setting (eos-aperture) are driven by your choice of lens (Listing 3). Also note that the path following --get-config = must match your camera model.

#### **Taking a Series of Pictures**

In the example provided in Listing 4, gPhoto takes five pictures at ISO 200, aperture 2.8, at intervals of 10 seconds. It

automatically transfers the images to the directory from which you ran the command.

Because the camera transfers the images directly to the disk, without the use of intermediate storage, you don't even need a memory card for this step. However, make sure the camera does not generate RAW and JPG images at the same time; otherwise, the large RAW files will soon fill up the cache because the application only autotransfers and deletes the JPG images from

### Listing 3: Aperture Settings for Canon EOS

\$ gphoto2 --set-config capture=on \( \bar{Z}\)
--get-config=/main/\( \bar{Z}\)
capturesettings/eos-aperture

Label: EOS aperture Type: RADIO Current: 5.6 Choice: 0 1.4 Choice: 1 1.6 Choice: 2 1.8 (1/3)

(...)

Choice: 24 22

## Listing 4: Remotely Controlling the Camera

\$ gphoto2 --set-config capture=on 2
 --set-config eos-iso=200 2
 --set-config eos-aperture=6 2
 --frames=5 --interval=10 2
 --capture-image-and-download

cache memory. If the images are not automatically transferred to your computer, you can use --capture-image instead of --capture-image-and-download.

If you do not want to limit the number of images and let gPhoto take snapshots until your disk is full, or the battery is dead, delete the *--frames* switch from Listing 4. If you want the software to perform some action after transferring an image, you can specify the *--hook-script = File* option, which will launch the specified script (*File*; e.g., to rename or move an image, upload an image to an FTP server, or even send an email).

### Table 1: gPhoto Data Management Switches

Switch	Function
list-folders	Output list of subdirectories
list-files	Output file list
mkdir=Folder	Create directory (Folder)
rmdir=Folder	Delete directory (Folder)
num-files	Show number of files
get-all-files	Get all files in directory
get-all-raw-data	Get all raw data in directory
get-all-audio-data	Get all audio data in directory
delete-all-files	Delete all files in directory
upload-file=File	Upload files (File) to camera
folder=Folder	Specify the camera directory (Folder)
recurse	Recursive
no-recurse	Non-recursive
storage-info	Memory card information
new	Process only new files
force-overwrite	Overwrite files without prompt

#### INFO

- [1] Nikon Camera Control: http://imaging.nikon.com/products/ imaging/lineup/software/control\_ nro2/
- [2] gPhoto: http://www.gphoto.org
- [3] digiKam: http://www.digikam.org
- [4] Remote control cameras: http://www.gphoto.org/doc/remote/

IE AUTHOR

Christian Baun is a doctoral student at the Steinbuch Center for Computing (SCC), Forschungszentrum Karlsruhe. His focus is on cloud computing, virtualization, and (free) operating systems.